

E-Z-Go RXV 4-Passenger Flip Flop Seat Kit Installation Instructions

1. Remove top canopy using 15mm tooling. If re-installing top canopy, keep front strut installed and prop rear of top; save hardware.
2. Remove front seat back cushion using Torx tooling; save hardware.
3. Remove seat back support brackets using 15mm tooling; save hardware. Remove boots, discard.
4. Remove access panel; save hardware.
5. Remove 2 bolts from rear bag well area using Torx tool; save hardware.
6. Install new Seat Back Brackets using existing hardware from Step 3; do not tighten.
7. Install new Seat Back Assembly Boots.
8. Install access cover removed in Step 4.
9. If reinstalling top canopy, install rear top struts removed in Step 1.
10. Attach front seat back cushion to new Seat Back Brackets using Torx tooling and hardware from Step 2. Tighten hardware from Step 6. **See Figure 1.**
11. Install Vertical Support Bracket into bagwell using Torx tooling, reusing hardware from Step 5. **See Figure 2.**
12. Install Flip Flop frame to Rear Seat Back Brackets. **See Figure 3.**
Use: **Hardware Bag # 1** with 17mm tooling. M10-1.5x50 hex bolts, washers and nuts.
13. Attach Vertical Support Bracket to Flip Flop Frame.
Use: **Hardware Bag # 2** with 17mm tool. M10-1.5x25 hex bolts, washers and nuts.
14. Attach Footplate to the Vertical Support Bracket. **See Figure 4.**
Use: **Hardware Bag # 2** with 17mm tool. M10-1.5x25 hex bolts, washers and nuts.
15. Attach Hand Rails to Flip Flop Frame.
Use: **Hardware Bag #3** with #3 Phillips screw driver. M10-1.5x50 Phillips truss head bolts, washers and nuts.
16. Attach Hand Rails to Footplate.
Use: **Hardware Bag #4** with 17mm tool. M10-1.5x70 shoulder hex bolts, washers and nuts.
17. Attach Rear Seat Back Cushion to Seat Kit Seat Back Bracket.
Use: **Hardware Bag #5** with 10mm tool. M6-1.0x45 hex bolts with washers.
18. Install Seat Kit Seat Back Bracket between Handrails. **See Figure 5.**
Use: **Hardware Bag #6** with Phillips Head tool. M8-1.5x50 Phillips head bolts, washers and nuts.
19. Install Rear Seat Bottom Cushion.
Use: **Hardware Bag #6** with #2 Phillips head tool. M5.5x38 wood screws.



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5

Bill of Material

- (2) Rear Seat Supports – Driver & Passenger
- (2) Rear Seat Support Boots
- (1) Vertical Support Bracket
- (1) Flip Flop Frame
- (1) Footplate
- (2) Handrails
- (1) Rear Seat Back Bracket
- (1) Rear Seat Back Cushion
- (1) Rear Seat Bottom Cushion
- (1) Box of Hardware

Box of Hardware

- (2) M10-1.5x50 hex bolts
- (2) M10-1.5x25 hex bolts
- (4) M10-1.5x50 Phillips head bolts
- (2) M10-1.5x70 shoulder hex bolts
- (24) M10 washers
- (12) M10-1.5 nyloc nuts
- (4) M6-1.0x45 hex bolts
- (4) M6 washers
- (4) M8-1.5x45 Phillips head bolts
- (8) M8 washers
- (4) M8-1.25 nyloc nuts
- (8) M5.5x38 wood screws

Box of Hardware	Bag #1	Bag #2	Bag#3	Bag#4	Bag#5	Bag#6
(2) M10-1.5x50 hex bolts	2					
(4) M10-1.5x25 hex bolts		4				
(4) M10-1.5x50 Phillips Head Bolts			4			
(2) M10-1.5x70 shoulder hex bolts				2		
(24) M10 washers	4	8	8	4		
(12) M10-1.5 nyloc nuts	2	4	4	2		
(4) M6-1.0x45 hex bolts					4	
(4) M6 washers					4	
(4) M8-1.5x50 Phillips Head Bolts						4
(8) M8 Washers						8
(4) M8-1.25 Nyloc Nuts						4
(8) M5.5x38 wood screws						8

Quick Install Guide

- Hardware Bag #1** Install Flip Flop Frame to Rear Support Struts. [Page 1, Step 12]
- Hardware Bag #2** Attach Vertical Support Bracket to Flip Flop Frame. [Page 1, Step 13]
Attach Footplate to Vertical Support Bracket. [Page 1, Step 14]
- Hardware Bag #3** Attach Hand Rails to Flip Flop Frame. [Page 1, Step 15]
- Hardware Bag #4** Attach Hand Rails to Footplate. [Page 1, Step 16]
- Hardware Bag #5** Attach Rear Seat Back Cushion to Seat Kit Seat Back Bracket. [Page 1, Step 17]
- Hardware Bag #6** Install Seat Kit Seat Back Bracket between Handrails. [Page 1, Step 18]
Install Seat Bottom Cushion. [Page 1, Step 19]